# Isco 701 pH/ Temperature Module

## **Installation and Operation Guide**





Part #60-9003-065 Copyright © 1995. All rights reserved, Teledyne Isco, Inc. Revision G, May 9, 2007

## Foreword

This instruction manual is designed to help you gain a thorough understanding of the operation of the equipment. Teledyne Isco recommends that you read this manual completely before placing the equipment in service.

Although Teledyne Isco designs reliability into all equipment, there is always the possibility of a malfunction. This manual may help in diagnosing and repairing the malfunction.

If the problem persists, call or e-mail the Teledyne Isco Technical Service Department for assistance. Simple difficulties can often be diagnosed over the phone.

If it is necessary to return the equipment to the factory for service, please follow the shipping instructions provided by the Customer Service Department, including the use of the **Return Authorization Number** specified. **Be sure to include a note describing the malfunction.** This will aid in the prompt repair and return of the equipment.

Teledyne Isco welcomes suggestions that would improve the information presented in this manual or enhance the operation of the equipment itself.

Teledyne Isco is continually improving its products and reserves the right to change product specifications, replacement parts, schematics, and instructions without notice.

Custome	r Service			
	Phone:	(800) 2	228-4373	(USA, Canada, Mexico)
		(402) 4	464-0231	(Outside North America)
	Fax:	(402) 4	465-3022	
	Email:	IscoCS	SR@teledyne	e.com
Technica	l Service			
	Phone:	(800) 7	775-2965	(Analytical)
		(800) 2	228-4373	(Samplers and Flow Meters)
	Email:	IscoSe	ervice@teledy	yne.com
	Return equipme	ent to:	4700 Super	ior Street, Lincoln, NE 68504-1398
Other Correspondence				
	Mail to:		P.O. Box 82	531, Lincoln, NE 68501-2531
	Email:		IscoInfo@te	eledyne.com
	Web site:		www.isco.co	om

#### **Contact Information**

## Table of Contents

## Section 1 Introduction and Programming

.1 Overview
.2 Function of the Probe 1-1
.3 How the pH Probe Works 1-2
.4 Technical Specifications 1-3
.5 Programming Notes 1-4
.6 Programmed Enable 1-4
.7 Installing the Module 1-7
.8 Installation Checklist 1-7
.9 Calibrating the pH Module 1-7

## Section 2 Installation

2.1	Installation Guidelines    2      2.1.1 Stream Conditions    2      2.1.2 Vertical Mounting    2      2.1.3 Horizontal Mounting    2	2-1 2-1 2-1 2-1 2-1
2.2	2.1.4 Installation in Round Pipes	2-2 2-2
	2.2.1 Spring Rings 2   2.2.2 Universal Mounting Rings 2	2-2 2-4
	2.2.3 U-Channel or Invert Mounting 2   2.2.4 Power-Actuated Stud Gun 2	2-7 2-7
2.3	2.2.5 Completing the Sensor Installation	2-7 2-8
2.4	Other Installation Methods    2      2.4.1 Rectangular, Trapezoidal, and Earthen Channels    2      2.4.2 U-Channels    2	2-8 2-8 2-8

## Section 3 Maintenance

. 3-1
. 3-1
. 3-2
. 3-2

#### **Appendix A Accessories**

#### Appendix B Material Safety Data

## List of Figures

- 1-1 Programming the sampler to use the 701 Module ...... 1-5
- 1-2 Quick View: Programming the sampler to use the 701 Module ...... 1-6

2-1	Sensor Installed on a Spring Ring	2-3
2-2	Universal Mounting Ring Parts	2-6
2-3	Universal Mounting Ring Adjustment	2-7

## Section 1 Introduction and Programming

1.1 Overview

The 701 pH/Temperature Module is one of Isco's interchangeable modules for the 6700 Series Samplers. The module uses a pH probe with an internal temperature sensor to measure the acidity or alkalinity and the temperature of a liquid.

You can install the module only on a 6700 Series controller. The pH probe can be used in nearly any installation where it can be mounted and retrieved for periodic maintenance and calibration.

## 

The module has not been approved for use in hazardous locations as defined by the National Electrical Code. Before installing any device in a dangerous location review the safety precautions in the sampler manual. Check applicable guidelines, codes, and regulations of federal, state, city, and county agencies.

## 1.2 Function of the Probe

The pH probe measures the acidity or alkalinity of an aqueous solution by determining the relative quantity of dissociated hydrogen ions, H+ (actually H30+) in the solution. A larger quantity of H+ ions indicates acidity, while a smaller quantity of H+ ions indicates alkalinity. The H in pH stands for Hydrogen and the p stands for power.

The normal scale for pH runs from 0 to 14, with 0 being most acidic and 14 being most alkaline. Distilled water at 25° C is neutral at 7, based on the fact that the dissociation constant (number of H<sup>+</sup> and OH<sup>-</sup> [hydroxyl] ions present) for pure water at 25° C is  $10^{-7}$ .

A dissociation constant is a number that indicates the amount of ionic dissociation occurring for a given substance after it is dissolved in aqueous solution. Dissociation constants vary widely for substances depending on the nature of the chemical bonds within the substance.

Each number on the pH scale between 7 and 0 equals a tenfold increase in  $H^+$  ion concentration. Each number between 7 and 14 equals a tenfold decrease of  $H^+$  ion concentration. The measurement of wastewater pH is commonly made to monitor the effect of treatment chemicals added to raise or lower the pH.

Water that has been used for various industrial processes may deviate substantially from 7. Chemicals are often added to the water to bring the pH close to that of neutral water, which is 7. For example, if the effluent has a concentration of heavy metal ions, they must be removed before discharge. Raising the pH of solutions containing transition-metal ions will cause them to precipitate, which can be removed as sludge. The resultant solution will be high in pH and will require acid to neutralize it. The pH probe is intended for use in applications where there are sulfide and/or metal ion concentrations. Itis recommended for applications where poisoning ion concentrations are greater than 100 parts per billion. The pH probe is a combination of two electrochemical half-cells. Together they provide a low-voltage signal that corresponds to the hydrogen-ion concentration of a solution. If you look at the pH probe, you will see a glass bulb on one end. This is called the *glass mono electrode*. The glass is of a special composition sensitive only to hydrogen ions. This electrode is exposed to the solution to be measured. The specific sensitivity to hydrogen ions prevents interference from other ions that may be present in the solution. The glass membrane produces an electrical potential proportional to hydrogen ion activity. The other electrode, called the *reference electrode*, completes the circuit between the glass electrode and the solution.

The two electrodes can be separate, or built into a single housing. The Isco pH probe combines both electrodes in a single housing and also contains an amplifier to reduce the extremely high impedance of the circuit. This improves the reaction of the probe to stray capacitance and reduces interference caused by electrical noise in the vicinity.

Like any other chemical reaction, pH measurement is affected significantly by temperature. Consequently, temperature compensation is provided. The Isco pH probe has a built-in temperature sensor that is exposed for faster response.

When the ion selective electrode and the reference electrode are connected to a high impedance voltmeter and submerged in solution, ions move to the surface of the membrane. The electrical charge on the ions creates a potential difference across the barrier between the solution and the membrane. This voltage difference is proportional to the activity of the ion in solution.

The potential translates into a reading of pH. With the module, the voltage is sent first to a preamplifier inside the probe to reduce the impedance of the circuit and improve the signal to noise ratio, and then on to the module.

#### 1.3 How the pH Probe Works

## 1.4 Technical Specifications

The following table contains technical data for the Isco 701 pH/Temperature Module and Probe, including weight, physical dimensions, materials, and operational specifications.

Table 1-1 Technical	Specifications for the 701 pH/Temperature Module		
General Notes: 1. All weights may vary ±0.2 lb (±0.1 kg). 2. All lengths may vary ± <sup>1</sup> / <sub>4</sub> inch (±0.64 cm).			
Module Weight:	1.1 lbs (0.5 kg)		
Sensor Weight:	0.9 lbs (0.4 kg)		
Module Dimensions:	4.9 x 5.7 x 2.0 inches (12.4 x 14.5 x 5.1 cm)		
Module Material:	Polystyrene		
Operational Temperature:	32°F to 120°F (0°C to 49°C)		
Storage Temperature:	0°F to 140°F (-18°C to 60°C)		
Module Enclosure:	NEMA 4X and 6, IP67		
Power:	Provided by sampler.		
Memory:	Nonvolatile programmable Flash. Can be field updated through the sampler.		
Readings:	Programmable through the sampler at 1, 2, 5, 10, 15, and 30 minute intervals.		
pH Resolution:	0.1 pH unit		
Temperature Resolution:	0.20°F (0. 10°C)		
Range:	0 to 14 pH units		

Table 1-2 Techni	cal Specificatio ns for the pH/Temperature Probe
Sensor Dimensions:	3/4" dia. NPT, 6 inches long (1.9 cm dia., 15.2 cm long)
Cable Length:	25 feet (7.6 m)
Probe material:	Stainless Steel
Cable Material:	PVC
pH Range:	0 to 14 pH units
pH Amplifier Accuracy:	±0.1 pH units from 0 to 11.9 pH. ±0.2 pH units from 12.0 to 14.0 pH
Liquid Junction Configuration:	Annular
Element Type:	Silver-Silver Chloride (Ag-AgCl)
Liquid Junction Material:	Porous PTFE/FEP
Reference Electrolyte:	Double Junction – Inner Chamber: KCL-AgCI – Outer Chamber: KNO3
Temperature Range:	32°F to 230°F (0°C to 110°C)

1.5 Programming Notes	When a module is installed, the sampler adds the necessary screens for programming. These screens appear in Figures 1-1 and 1-2.
	☑ Note
	An * (asterisk) appears next to the reading if the module was unable to take a reading. If an * appears, the reading displayed is the last available reading.
	You must have the module installed before turning the controller on. When the controller is turned on it looks for a module. If the module is installed after the controller is turned on you will not be able to program the sampler for use with the module. For more information see the Programming section in the sampler manual.
1.6 Programmed Enable	When a pH/Temperature Module is installed, additional enable options are available. The options will be pH <i>or</i> TEMPER- ATURE, or pH <i>and</i> TEMPERATURE. For more information, see Sampler Enable in the sampler manual.



Figure 1-1 Programming the sampler to use the 701 Module



Figure 1-2 Quick View: Programming the sampler to use the 701 Module

1.7 Installing the Module	To install the module:	
	1. Turn the sampler off.	
	2. Remove the connector cap in the module bay and move it aside.	
	3. Slide the module into the bay.	
	4. Push the module to be sure the connector is firmly seated.	
	To remove the module, turn the sampler off. Depress the silver button and pull the module from the bay. Replace the connector cap in the module bay.	
1.8 Installation Checklist	1. Install the module then turn the sampler on.	
	2. Program the sampler and calibrate the module's pH read- ing.	
	3. Install the probe.	
	4. Connect the probe's cable to the module.	
	5. Set up the sampler. See the sampler manual.	
	6. Run the program.	
1.9 Calibrating the pH Module	The pH module uses a two-part calibration for the pH probe using commercially prepared calibrated buffer solutions. For accurate readings you must clean and recalibrate the probe on a regular basis. How often depends on the operating conditions.	
	Flow streams with a high grease content will coat the sensing surfaces of the probe quickly, clogging them and slowing the response time or stopping it altogether.	
	Calibrating the module can be done with two or three points. With two point calibration (pH 4 and 7, pH 4 and 10, or pH 7 and 10) the module creates a linear relationship from pH 0 to 14	

through these two points. With three point calibration (pH 4, 7, and 10) the module creates a linear relationship from pH 0 to 7 through pH 4 and 7 and creates another linear relationship from

pH 7 to 14 using calibration points pH 7 and 10.

## Section 2 Installation

## 2.1 Installation Guidelines

## Note

		Remember to unscrew the rubber guard cap from the sensing end of the probe after you install it, or the probe will be unable to sense the flow stream.
		The guard cap is to protect the probe during shipment and storage and to keep the glass membrane and liquid junction from drying out. If you remove the probe from the stream for any reason, clean it and replace the cap after filling with 4.0 buffer solution. Never store the probe dry or without the cap in place.
		Always mount the probe in an easily-accessible location. The probe will need cleaning, calibration, and eventual replacement.
2.1.1	Stream Conditions	Install the probe only in streams that have continuous flow.
		For proper operation, there must also be enough flow or liquid to submerge the sensing end of the probe completely.
		If flow in the stream is intermittent (dry for periods of time), the pH probe sensing bulb will dry out and its response time will become slow. This will be a problem in situations where pH changes rapidly. If the probe remains dry long enough, it will be ruined. Never let the sensing end of the probe dry out.
		Installation in streams with high grease content may result in poor performance and require frequent maintenance.
		The pH Probe will operate satisfactorily mounted either horizon- tally or vertically in the stream. However, horizontal mounting is more secure, and presents less of a trap for debris.
2.1.2	Vertical Mounting	If you mount the pH probe vertically, mount it securely. Never suspend the probe by its cable, particularly over streams that run at high levels and high velocities, or streams that carry debris which could damage the sensor.
2.1.3	Horizontal Mounting	For horizontal mounting, the probe fastens to a sensor carrier that snap-fits to an Isco mounting ring. The mounting rings fit various diameters of round pipes. They are held in place by the outward force of spring pressure in the smaller sizes and by a screw arrangement in the larger sizes. After mounting the probe in the ring or strap, route the cable out of the stream so it will not trap debris that could clog the sewer. Isco recommends mounting

the probe facing upstream, as there is a stop on the sensor carrier that is not effective when the probe is facing down stream.

# 2.2 Installation in Round Consult your Isco Mounting Rings instruction manual for detailed hardware information.

The following sections describe sensor installation using the two options available for mounting sensors in pipes or round-bottomed flow streams. For pipes up to 15" (38.1 cm) in diameter, **stainless steel self-expanding mounting rings** (**Spring Rings**) are available. For pipes larger than 15" in diameter, Teledyne Isco offers the **Scissors Rings** (Universal Mounting **Rings**).

# 2.2.1 Spring Rings To install a spring ring, you compress the ring, slip it inside the pipe, and then allow it to spring out to contact the inside diameter of the pipe. The inherent outward spring force of the ring firmly secures it in place. A typical self-expanding mounting ring (with a probe mounted on it) is shown in Figure 4-8.

These mounting rings are available for use in pipes with inside diameters of 6" (15.2 cm), 8" (20.3 cm), 10" (25.4 cm), 12" (30.5 cm), and 15" (38.1 cm). The Isco part numbers for the various size mounting rings available are listed in Appendix A. These part numbers include not only the ring, but also the miscellaneous hardware necessary to mount the sensor on the ring.

## 

Always wear leather gloves when handling the rings (either type). The metal is finished, but there is still a possibility of cutting your hands on the edges.

Attaching the Sensor to the Ring

pH probe carrier part #60-3208-001

e Attach the sensor by snapping the probe carrier into the slots in the ring (Figure 2-1).

This method of attaching the sensor allows for easy removal in case servicing becomes necessary.



Figure 2-1 Sensor Installed on a Spring Ring

Completing the assembly

To complete the sensor-spring ring assembly procedure, attach the sensor cable to the downstream edge of the ring. Follow the cable routing shown in Figure 4-8. Other routing directions may affect measurement accuracy. The cable can actually create a stilling well downstream from the sensor, causing the level to read low. Use the self-locking plastic ties supplied with the ring. Install the ring in the pipe by compressing it. Press inward on both sides and slide the ring into the pipe.

Route the sensor cable out of the stream and secure it in position by placing the ties through the holes in the mounting ring and then locking them around the cable, as shown. To prevent debris from catching on the cable, it is important to attach the cable to the mounting ring so it offers as little resistance to the flow as possible.

The spring ring may need anchoring. Under conditions of high velocity (greater than 5 feet per second or 1.5 meters per second), the ring may not have sufficient outward spring force to maintain a tight fit inside the pipe. The ring may start to lift off the bottom of the pipe in a waving fashion, or may even be carried downstream.

This problem is more prevalent in the larger diameter pipes (10", 12", and 15", and in pipes with smooth inside surfaces, such as plastic pipes). If any of these conditions are present, or if movement of the mounting ring is detected or suspected, you must anchor the ring in place. You can do this by setting screws through the ring into the pipe, or by other appropriate means. If there is a problem with the smaller diameter rings, it may be sufficient to simply increase the outward spring force of the ring by bending it into a less round configuration.

2.2.2 Scissors Rings For pipes larger than 15" in diameter, Teledyne Isco offers the adjustable Scissors Ring (also known as the Universal Mounting Ring). This device consists of two or more metal strips that lock together with tabs to form a single assembly. There is a base section where the sensors are mounted, one or more extension sections (usually), and a scissors section at the top that expands the entire assembly and tightens it inside the pipe. The scissors mechanism includes a long screw that increases the width as it is tightened.

The assembled rings fit pipe diameters from 16" to 80". Secure the unit in place by tightening the scissors mechanism with a  $\frac{5}{8}$ " socket wrench or other suitable tool. Ring sections are .040" thick half-hard 301 stainless steel sheet. All other parts are also stainless steel, except for the plastic cable ties in the hardware kit.

Each extension, 1, 2, 3, and 4, adds 9.0", 21.5", 31.5", or 41.5", respectively, to the circumference of the ring. Used alone, the base section fits pipe that is approximately 16" to 18" in diameter. The 9.0" (the smallest) extension exists so that in larger pipe sizes, where large variations in circumference can occur, you can use one or two of these extensions to take up or remove slack, to bring the scissors mechanism into a position where it can be effectively tightened.

Mounting ring kits are available for different pipe sizes. A kit is also available for partial pipe applications (see your Mounting Rings manual). For a listing of part numbers and ordering information, see Appendix A.

To prevent debris from catching on the cable, it is important to attach the cable to the mounting ring so it offers as little resistance to the flow as possible. Attach the sensor cable to the downstream edge of the ring, using the self-locking plastic ties supplied with the ring. Place the ties through the holes in the edge of the mounting ring and then lock them around the cable.



2.3 Scissors Ring Adjustment

2.3.1 Street Level Installation System	The Street Level Installation System provides a way to install the probe in a round pipe without entering a manhole. This system uses multi-section poles and expansion rings that fit 6, 8, 10, 12, and 15 inch round pipes in manholes as deep as 15 feet. The system includes an instruction manual. Contact the factory or your representaive for details.
2.4 Other Installation Methods	Isco's mounting hardware can be installed or adapted for use in many channels. The paragraphs below list additional pH probe installation methods.
2.4.1 Rectangular, Trapezoidal, and Earthen Channels	The Sensor Mounting Plate (part #68-3000-051) may be used to mount the pH probe in these channels. The stainless steel plate has tabs to mount up to three sensors. It is secured in concrete channels by driving studs into the channel bottom and bolting the plate to the studs. In an earthen channel, the plate can be held in place by driving in stakes.
2.4.2 U-Channels	It is possible to mount the pH probe and carrier in a U-channel with a scissors ring base section. Attach the base section to the channel wall with studs fired from a power-actuated stud gun.

## Section 3 Maintenance

#### 3.1 Storage and Maintenance of pH Probe

3.2 Probe Life

Whenever the pH probe is in storage or out of solution, you must be careful to keep the glass sensor bulb wet. Always store the probe with the rubber cover screwed completely over the threaded end of the sensor. Exposure to air causes the glass membrane to dry out. This makes it very slow to respond in solution. Prolonged or repeated dehydration of the bulb may ruin the probe completely.

The pH sensitive glass can become conditioned to its environment, especially when it is continuously exposed to high pH (10 and above) solutions. The glass does have a memory and will respond slowly when exposed to a lower pH solution after having been in a high pH solution for any significant period of time.

Storage of a pH probe in a 4.0 buffer solution is recommended as this has a regenerative effect on the glass and does not put a memory on it. Tap water will work if 4.0 buffer solution is not available. Deionized water is good for quick rinses to clean the element, but not for prolonged storage of an electrode. Continuous exposure of the ion-sensitive membrane to a wetted, but nonionic solution will improperly condition the membrane.

The reference electrode is also adversely affected when allowed to dry out. Salt crystals from the electrolyte or precipitates of the solution measured will form salt bridges either within or on the surfaces of the liquid junction, causing the reference to be less conductive and resulting in a higher reference impedance.

This condition will typically worsen until the unit no longer functions. Soaking the reference electrode in a 4.0 pH solution, or tap water if the buffer is not readily available, may bring the reference back to life. Boiling the electrode in 4.0 buffer solution or tap water could revive the electrode in more severe situations. If none of these works, replace the probe.

All pH probes are consumable items, meaning that they will eventually fail and have to be replaced.

During the working life of the probe you will have to clean and recalibrate it periodically. Grease and debris will interfere with the probe's ability to measure pH accurately. Grease will coat the end of the probe. Grease is an insulator, keeping the ions from reaching the glass membrane and porous liquid junction, thus failing to create a voltage potential. The pH probe has reached the end of usable life when you can no longer calibrate the probe (after cleaning) to 4 and 7. Another indication of end of life is when the probe eventually calibrates satisfactorily, but takes too long to stabilize (more than 10 minutes).

Such a probe could not possibly respond to a situation of rapidly-changing pH. If your situation requires faster response, you might consider end-of-life to have occurred when stabilization time reaches five or seven minutes.

3.3 Flash Memory and Software Upgrades The module has Flash memory to store its software. With Flash technology, you can upgrade your module's software without sending it back to the factory or replacing the chip. Simply connect a computer to the sampler with the module installed and run the Flash update program.

## Mote

When updating the Flash memory the module must be attached to the sampler and power must be supplied to the sampler.

3.4 Repairing the Module

The module has no user-serviceable parts. Its case is completely sealed to protect the internal components. To repair the unit, the case must be broken open and replaced. If you think your module requires repair, contact Teledyne Isco's Technical Service Department for information on returning it to the factory.

# Appendix A Accessories

Accessories and replacement parts can be purchased by contacting Isco's Customer Service Department.

Table A-1Accessories	
pH Module w/ Probe (includes module, probe, pH 4, 7, and10 buffers, rinse, and manual)	68-6700-052
pH/Temp Sensor (includes module, probe, pH 4, 7, and10 buffers, rinse, and manual)	68-6700-054
pH/Temp Probe	60-9004-126
pH Module Manual	60-9003-065
pH Probe Mount Assembly	60-3208-001
Electrode Rinse Solution	479-0010-00
pH 4 Buffer	479-0001-04
pH 7 Buffer	479-0001-07
pH 10 Buffer	479-0001-10
Spring Mounting Ring 6" Dia	68-3200-007
Spring Mounting Ring 8" Dia	68-3200-008
Spring Mounting Ring 10" Dia	68-3200-009
Spring Mounting Ring 12" Dia	68-3200-010
Spring Mounting Ring 15" Dia	68-3200-011
Extension Kit For 16"-23" Pipe	68-3000-042
Extension Kit For 16"-36" Pipe	68-3000-043
Extension Kit For 39"-43" Pipe	68-3000-044
Extension Kit For 45"-49" Pipe	68-3000-045
Extension Kit For 58" - 62" Pipe	68-3000-046
Extension Kit For 72" Pipe	68-3000-047
Extension Kit For 16"-80" Pipe	68-3000-048
Base Button Assembly	60-3004-171
Scissors Adjustment Assembly	60-3004-170

## Appendix B Material Safety Data

This appendix to the manual provides Material Safety Data Sheets for the solutions used with the pH probe.

Teledyne Isco cannot guarantee the accuracy of the data. Specific questions regarding the use and handling of the products should be directed to the manufacturer listed on the MSDS.

SHEET 1 OF 2

Orion Research Incorporated THE SCHRAFFT CENTER 529 MAIN STREET, BOSTON, MA 02129 USA TELEPHONE 617-242-3900

#### I. PRODUCT IDENTIFICATION

PRODUCT NAME	CATALOG NO.	EFFECTIVE DATE
perpHect Butter 4	910410, 910425, 910450	06/01/91
HAZARDOUS DOT	IATA	
SHIPMENT LABELLING	None	
PREPARED BY	TITLE Quality Assurance Chemist	
APPROVED BY ym Orlowk	TITLE Director Regulatory Matter	*8

## II. HAZARDOUS INGREDIENTS (IDENTITY INFORMATION)

HAZARDOUS COMPONENTS' SPECIFIC CHEMICAL IDENTITY: COMMON NAME(S)	CAS NO.	*	OSHA PEL	ACGIH TLV	LD 50 mg/Kg
Potassium Hydrogen Phthalate (KHP)	877-24-7	1.01	None	None	None listed.
Amaranth Red Dve (C20H11N2O10S3.3Na)	915-67-3	0.005	None	None	1,000 (IPR-MUS)
" De-Ionized Water (H <sub>2</sub> O)	7732-18-5	98.985	None	None	190,000 (IPR-MUS)

#### III. PHYSICAL DATA

BOILING POINT 760 min Hg	FREEZING POINT
100° C	0° C
SPECIFIC GRAVITY , Mgo + 1 .0	VAPOR PRESSURE @ NA '
рн @ °C 25 4.01	SOLUBILITY IN WATER, % BY WT. @ Miscible
VOLATILES, % BY WT.	EVAPORATION RATE (BUTTL_ACETATE = 1)
VAPOR DENSITY (AR = 1) N A	
APPEARANCE AND ODOR	

Light Red, Odoriess Llauid

#### IV. FIRE AND EXPLOSION HAZARD DATA

FLASH POINT (near metrico) Not Flammable	AUTOIGNITION TEMPERATUR	Е
FLAMMABLE LIMITS IN AIR, % BY VOLUME:	LOWER N A	UPPER N A
EXTINGUISHING MEDIA Water, CO <sub>2</sub> , Dry Chemical, Foam or Spray		
SPECIAL FIRE-FIGHTING PROCEDURES		
None		
UNUSUAL FIRE AND EXPLOSION HAZARDS	<u> </u>	
None		

<sup>6</sup> Chemicals which are not classified as hazardous per U.S. OSHA guidelines (29CFR) Parts 1915.2 or 1916.2) or the Massachusetts Substance List (105CMR670.000 Appendix A) will not necessarily be listed on this form even though one or mcre may be a constituent of this product.

Liability is expressly discislined for any lose or injury stleing out of the use of this information or the use of any materials designated. Sale use of the materials is the responsibility of the user.

Document No. 205568-001

Rev. A

Printed in U.S.A. Form MSDS/0191

NA = Not Available/Not Applicable

\* \* Non-hazardous Component

SHEET 2 OF 2

PRODUCT NAME: perpHect Buffer 4

CATALOG NO.: 910410, 910425, 910450

V. REACTIVITY DATA

STABILITY:		CONDITIONS TO AVOID	
UNSTABLE	STABLE D	None	
INCOMPATIBILITY M	TERIALS TO AVOID		
1		Nitric Acid	
HAZARDOUS DECOMP	OSITION PRODUCTS		
		None	
HAZARDOUS POLYME	RIZATION:	CONDITION TO AVOID	
MAY OCCUR	WILL NOT OCCUR	None	

#### VI. HEALTH HAZARD DATA

ROUTE(S) OF ENTRY:	INHALATION?	SKIN7		INGESTION?		
	No	Y	e <b>s</b>	Yes		
HEALTH HAZARDS (ACUTE AN	CHRONIC]					
Acute: Low hazard because	e of low concentration of a	alts.	Chronic: Po	asible skin irritant fo	r prolonged exposure.	
CARCINOGENICITY:	NTP?	IARC MONOGRAPHS		OSHA REGULATED	?	
	(Suape	ci)	(Animal Poe	itive)	(Not Found)	
SIGNS AND SYMPTOMS OF I	EXPOSURE			· · · · · · · · · · · · · · · · · · ·		
MEDICAL CONDITIONS GEN	ERALLY AGGRAVATED BY EX	POSURE		· · · · · · · · · · · · · · · · · · ·	<u></u>	
Possible aggravation of i	SKIN GISOSOS,					
EMERGENCY AND FIRST AIL	PROCEDURES					
Wash contact area with v	vater. If ingested, give la	rge amounts of water a	nd consult	bhysician.		

#### VII. PRECAUTIONS (SAFE HANDLING AND USE)

STEPS TO BE TAKEN IN CASE MATERIAL IS RELEASED OR SPILLED

Wash down drain with water if local law allows.

WASTE DISPOSAL METHOD

Consult with and observe all federal, state, and local laws when disposing of this product.

PRECAUTIONS TO BE TAKEN IN HANDLING AND STORING

Suitable for general storage. This product is not regulated under <u>SARA\_</u>Title III.

OTHER PRECAUTIONS

Not affected by Cal. Prop 65. NFPA Rating: Scale (0-4) Health 1, Fire 0, Reactivity 1, Specific - None.

#### VIII. CONTROL MEASURES

RESPIRATORY PR	TOTECTION (SECONT TITE)		
	None		
VENTILATION	LOCAL EXHAUST	SPECIAL	
ļ	No		No
1	MECHANICAL (CEMERAL)	OTHER	
	No		10
PROTECTIVE GLO	OVES	EYE PROTECTION	
	Yes (any type)		Salety Glasses
OTHER PROTECTI	VE CLOTHING OR EQUIPMENT		
	No		
WORKHYGIENIC	PRACTICES		
	No eating or drinking while working with t	his product.	

SHEET 1 OF 2

VrionResearchIncorporatedIHE SCHRAFFT CENTER529MAIN STREET, BOSTON, MA 02129USATELEPHONE617-242-3900

I. PRODUCT IDENTIFICATION

PRODUCT NAME	CATALOG NO.	EFFECTIVE DATE
parpHect Buller 7	910710, 910725, 910750	06/01/91
HAZARDOUS DCT	IATA	
SHIPMENT LABELLING: None	None	
PREPARED BY framed officiant	TITLE Quality Assurance Chemic	st
APPROVED BY OLOW	TITLE Director Regulatory Mat	lers

## II. HAZARDOUS INGREDIENTS (IDENTITY INFORMATION)

HAZARDOUS COMPONENTS <sup>®</sup> Specific Chemical Bentify Common Halfen	CAS NO.	*	OSHA PEL	ACGIH TLV	LD 50 mg/Kg
Potassium Phosphale (KH2PO4)	7778-77-0	0.284	None	None	None Listed
Sodium Phosphate (Na2HPO4)	7558-79-4	0.413	None	None	298 (IVN-DOG)
Sodium Chromete (Na2CrO4)	7775-11-3	0.013	50 ug/mg3	50 ug/m3	57 (IRR-RAT)
Potaselum Dichromate (K2CrO2)	778-50-9	0.003	50 ug /m3	50 ug/m3	37 (INR-RAT)
" De-Ionized Water (H2O)	7732-18-5	99.287	None	None	190,000 (ORL-DOG)

#### III. PHYSICAL DATA

BOILING POINT 760 mm lig	FREEZING POINT
100 <sup>0</sup> C	0o0
SPECIFIC GRAVITY (H20 = 1)	VAPOR PRESSURE @
1.0	• NA
pH @ *C	SOLUBILITY IN WATER, % BY WT. @
25 7.00	Miscible
VOLATILES, % BY WT.	EVAPORATION RATE (BUTYL, ACETATE = 1)
· NA	NA
VAPOR DENSITY (AIR = 1)	
NA	
APPEARANCE AND ODOR	
Liebt Velleur, Odestere 11	lauld

#### IV. FIRE AND EXPLOSION HAZARD DATA

FLASH POINT (TEST METHOD)	AUTOIGNITION TEL	MPERATURE
Not Flammable		NA
FLAMMABLE LIMITS	LOWER	UPPER
IN AIR, % BY VOLUME:	NA	NA
EXTINGUISHING MEDIA		
Water, CO <sub>2</sub> , Dry Chemical, Foam or Spray		
SPECIAL FIRE-FIGHTING PROCEDURES		
None		
UNUSUAL FIRE AND EXPLOSION HAZARDS		
None		

Chemicals which are not classified as hazardous per U.S. OSHA guidelines (29CFR Parts 1915.2 or 1915.2) or the Massachusetts Substance List (10SCMR670.000 Appendix A) will not necessarily be listed on this form even though one or more may be a constituent of this product.

Liability is expressly disclaimed for any loss or injury stising out of the use of this information or the use of any materials designated. Sale use of the materials is the responsibility of the user. Document No. 205569-001

Rev. A

.

Printed in U.S.A. Form MSDS/0191

NA = Not Available/Not Applicable

\* \* Non-hazardous Component

SHEET 2 OF 2 PRODUCT NAME: perpHect Buffer 7

#### CATALOG NO.:910710, 910725, 910750

V. REACTIVITY DATA

STABILITY:	CONDITIONS TO AVOID
UNSTABLE D STABLEY	
INCOMPATIBILITY (MATERIALS TO AVOI	))
	Magnesium and Sodium metale
HAZARDOUS DECOMPOSITION PRODUCTS	
	Possible evolution of fumes from phosphatos if heated.
HAZARDOUS POLYMERIZATION:	CONDITION TO AVOID
MAY OCCUR WILL NOT OCCUR	

## VI. HEALTH HAZARD DATA

ROUTE(S) OF ENTRY:	INHALATION?	SKIN?	INGESTION?	
	No	No	Yes	
HEALTH HAZARDS MOUTE AN	0 04040			
Low Hazard for both acut	e and chronic because of	low concentration of salts.		
CARCINOGENICITY:	NTP?	IARC MONOGRAPHS?	OSHA REGULATED?	
	Not Found	Not Found	Not Found	
SIGNS AND SYMPTOMS OF	EXPOSURE			
irritation of skin.				
MEDICAL CONDITIONS GEN	ERALLY AGGRAVATED BY E	POSURE		
Possible aggravation of	skin diseases.			
EMERGENCY AND FIRST AI	PROCEDURES		<u></u>	
Wash off contact area wi	th water. If ingested, give	e large amounts of water and	contact a physician.	

#### VII. PRECAUTIONS (SAFE HANDLING AND USE)

STEPS TO BE TAKEN IN CASE MATERIAL IS RELEASED OR SPILLED
Wash down drain with water if local law allows.
WASTE DISPOSAL METHOD
Consult with and observe all federal, alsie and local laws when disposing of this product.
PRECAUTIONS TO BE TAKEN IN HANDLING AND STORING
SARA This III: Releases of Na2HP04 are subject to reporting under Sec. 302 of Title III.
OTHER PRECAUTIONS
NFPA Rating: Scale (0-4) Fire 0, Health 0, Reactivity 0, Specific - None. Not affected by <u>CAL Proposition_65</u> .

## VIII. CONTROL MEASURES

RESPIRATORY PR	OTECTION (SPECIFY TYPE)			
		None		
VENTILATION	LOCAL EXHAUST		SPECIAL	
		No	No	
	MECHANICAL (GENERAL)		OTHER	
	1	No	No	
PROTECTIVE GLOVES			EYE PROTECTION	
		No	Salety Glasses	
OTHER PROTECTI	VE CLOTHING OR EQUIPMENT			
		Na		
WORK/HYGIENIC	PRACTICES			
		No esti	ing or drinking while working with this product.	

Sheet 1 of 2 Orion Research Incorporated THE SCHRAFFT CENTER 529 Main Street, Boston, MA 02129 USA Telephone 617-242-3900

I.	PRODUC	CT IDEN	TIFICA'	FION	
Product Name		Catalog No.		EffectiveD	ite
perpHect Buffer 10		91	1010, 911025	0	7/20/93
Hazardous DOT		IATA			
Shipment Labelling: None			None		
Prepared By		Title Quality /	Assurance Cher	nist	
Approved By	und	Title	Regulatory Ma	itters	
	$-\Lambda$				
II. HAZARDO	US INGRI	EDIENTS	(IDENTI	FY INFORM	IATION)
Hazardous Components*	CAS NO.	%	OSHA PEL	ACGIH TLV	LD
Specific Chemical Identity: Common Name(s)					50mg/Kg
Sodium Bicarbonate (NaHCO3)	144-55-8	0.209	None	None	4220 (ORL-RAT)
Sodium Carbonate (Na <sub>2</sub> CO <sub>3</sub> )	497-19-8	0.264	None	None	117 (PR-MUS)
Methylparaben (CgHqO <sub>3</sub> )	99-76-3	0.001	None	None	NA
FD&C Blue (C <sub>37</sub> H <sub>36</sub> N <sub>2</sub> O <sub>g</sub> S <sub>3</sub> *2Na)	384445-9	0.0005	None	None	5.5g 1Kg (SCU-RAT)TD Lo
**Deionized Water (H2O)	7732-18-5	99.526	None	None	190,000 (ORL-DOG)
	Ш. Р	HYSICAL	L DATA		
Boiling Point 750 mm Hg 100°C		Freezing Poi	at O°C		
Specific Gravity (H_0=1)	)	Vapor Press	ure @	NA	
pH @ °C		Solubility In	Water, % By	Wt @ Miscible	
Volatiles, % By Wt. NA		Evaporation	Rate OUTTL. AC	ETATE = 1) NA	
Vapor Density an - 1) NA					
Appearance and Odor Light blue, odorless I	iquid				
IV. FIF	E AND E	XPLOSI	ON HAZ	ARD DAT	A
Flash Point (Less Method) Not fla	mmable	Autoignition	Temperature	NA	
Flammable Limits		Lower		Upper	
in air, % by volume:			NA		NA
Extinguishing Media Water, CO <sub>2</sub> , Dry chemical. foam or spray					
Special Fire-Fighting Procedures None,	non-ilammable				
Unusual Fire and Explosion Hazards					
Chemicals which are not classified as house the second secon	na liabilita is	march diadai-	and for any las	Dec	ent No. 205570-001
per U.S. OSHA guidelines (29CFR Parts 1915.2 injury arising out of the use o			vea jor any los of this inform	vion Rev. C	
or 1916.2) or the Massachusetts Substance List or the use of any materials designated. Safe use					
(105CMR670.000 Appendix A) will not of the materials is the responsibility of the user.					
necessarily be listed on this form even though					
one or more may be a constituent of this product					
• NA Not available/not applicable			Printe	l in U.S.A.	
					1000011100

## ATI ORION MATERIAL SAFETY DATA SHEET Sheet 2 of 2

#### PRODUCT NAME: perpHect Buffer 10 Catalog No.: 911010, 911025 V. REACTIVITY DATA

Stability:	Conditions to Avoid	
Unstable Stable	e X	
Incompatibility (Materials to svoid	NaK alloy, $NH_4H_2PO_4$ , AL, $P_2O_5$ , $H_2SO_4$	
Hazardons Decomposition Products		
	CO <sub>2</sub> Upon heating to decomposition	
Hazardous Polymerization:	Condition to Avoid	
May Occur Will Not	Occur X None	

## VI. HEALTH HAZARD DATA

Route(s) Of Entry:	Inhalation?	Skin?	Ingestion?	
	No		Yes	Yes
Health Hazards (acute and chroni	ic)			
Acute: Non-hazardous due to the lo	w levels of salt presen	t. Chronic: Possible irritation c	of skin	
Carcinogenicity:	NTP?	LARC Monographs? ***	OSHA regulated?	
	Not found	(animal positive)		Not found
Signs and Symptoms of Exposure				
Irritation of skin				
Medical Conditions Generally Age	zravated By Exposure	e Could aggravate diseases of t	he skin.	
Emergency And First Aid Procedures				
Wash off contact area with water. If ingested, give large amounts of water. Contact physician.				

## VII. PRECAUTIONS (SAFE HANDLING AND USE)

Steps To Be Taken In Case Material Is Released Or Spilled	
Clean up and set aside for waste disposal.	
Waste Disposal Method	
Consult with and observe all Federal, State and Local laws when disposing of this product.	
Precautions To Be Taken In Handling And Storing	
Suitable for any general handling and storage.	
NFPA Rating: Scale (0-4) Fire 0, Health 1, Ractivity 0, Specific - None. Net affected by CAL Proposition 65	

## VIII. CONTROL MEASURES

Respiratory Prote	Ction (specify type)			
None				
Ventilation	Local Exhaust	Special		
	No	No		
Ventilation	Mechanical (General)	Other		
	No	No		
Protective Gloves	Yes	Eye Protection	Safety glasses	
Other Protective	Clothing Or Equipment			
	No			
Work/Hygienic Pr	actices			
	No eating or drinking while working with	this product		

## Teledyne Isco One Year Limited Factory Service Warranty \*

Teledyne Isco warrants covered products against failure due to faulty parts or workmanship for a period of one year (365 days) from their shipping date, or from the date of installation by an authorized Teledyne Isco Service Engineer, as may be appropriate.

During the warranty period, repairs, replacements, and labor shall be provided at no charge. Teledyne Isco's liability is strictly limited to repair and/or replacement, at Teledyne Isco's sole discretion.

Failure of expendable items (e.g., charts, ribbon, tubing, lamps, glassware, seals, filters, fittings, and wetted parts of valves), or from normal wear, accident, misuse, corrosion, or lack of proper maintenance, is not covered. Teledyne Isco assumes no liability for any consequential damages. This warranty does not cover loss, damage, or defects resulting from transportation between the customer's facility and the repair facility.

Teledyne Isco specifically disclaims any warranty of merchantability or fitness for a particular purpose.

This warranty applies only to products sold under the Teledyne Isco trademark and is made in lieu of any other warranty, written or expressed.

No items may be returned for warranty service without a return authorization number issued from Teledyne Isco.

The warrantor is Teledyne Isco, Inc. 4700 Superior, Lincoln, NE 68504, U.S.A.

\* This warranty applies to the USA and countries where Teledyne Isco Inc. does not have an authorized dealer. Customers in countries outside the USA, where Teledyne Isco has an authorized dealer, should contact their Teledyne Isco dealer for warranty service.

In the event of instrument problems, always contact the Teledyne Isco Service Department, as problems can often be diagnosed and corrected without requiring an on-site visit. In the U.S.A., contact Teledyne Isco Service at the numbers listed below. International customers should contact their local Teledyne Isco agent or Teledyne Isco International Customer Service.

## **Return Authorization**

A return authorization number must be issued prior to shipping. Following authorization, Teledyne Isco will pay for surface transportation (excluding packing/crating) both ways for 30 days from the beginning of the warranty period. After 30 days, expense for warranty shipments will be the responsibility of the customer.

Shipping Address:	Teledyne Isco, Inc Attention Repair Service 4700 Superior Street Lincoln NE 68504 USA		
Mailing address:	Teledyne Isco, Inc. PO Box 82531 Lincoln NE 68501 USA		
Phone:	Repair service: (800)775-2965 (lab instruments) (800)228-4373 (samplers & flow meters) Sales & General Information (800)228-4373 (USA & Canada)		
۲ Fax:	(402) 465-3001		
Email:	iscoservice@teledyne.com Web site: www.isco.com		

