

2) Internal Battery Packs

Most Proteus models can be ordered with Internal Battery Packs that accommodate, depending on the diameter of the Proteus, an array of AA-, C-, or D-cell batteries. The Internal Battery Pack is a handy way to power Proteus' in long-term logging deployments.



3) External Battery Packs

Most Proteus models can be fitted with easily-detachable External Battery Packs that accommodate, depending on the diameter of the Proteus, an array of AA-, C-, or D-cell batteries. The External Battery Pack is a handy way to power Proteus' in long-term logging deployments, but can be removed for easy manual Proteus operation.



4) Using Power from the Amphibian Field Display

If you insist on an old-school Data Display, a durable, versatile field PC called the Amphibian2 is also available. Attach an Underwater Cable to your Proteus. Or, you can use a Data Cable for work in the lab. Here's how it works:

- a) Attach one end of your Cable to your Proteus and the other end to the Amphibian2.
- b) Turn the Amphibian on and wait for the Start menu to appear. Touch Amp 2.2.7 to launch the Proteus control software.
- c) When you see the rolling-data display, your Proteus and Amphibian are ready to go.



7) Using Power from Your Own Battery or Other Power Source

In some instances, you may wish to power the Proteus with an alternate source of power - for instance with a solar-backed battery in telemetry applications – with the Optional Battery Cable. Here’s how it works:

- a) Attach a Cable to your Proteus.
- b) Attach the other end of the Cable to the Optional Battery Cable – it can only fit one way.
- c) Connect the leads from the Optional Battery Connector to your battery or other power source providing between 9 and 15 VDC, using the red wire for positive and the black wire for ground.
- d) If you are using a PC or laptop for your display device, connect the remaining connector on the Optional Battery Cable to Proteus’ USB Adapter Cable and then to a USB port on your PC.
- e) Launch your Proteus Control Software as usual.
- f) If you are using an Amphibian for your display device, connect the last connector on the Optional Battery Cable to the Amphibian. Turn the Amphibian on and wait for the Start menu to appear. Touch Amp 2.2.7 to launch the Proteus control software.



Note: Do not connect your Optional Battery Cable to any power source that is connected to a highvoltage power source (such as a 110 VAC power plug on the wall). It’s very dangerous to play with water and high voltage.

8) Using Power from the USB Adapter Power Connection

If your Proteus has a large number of sensors, or if your Cable is too long, your PC's USB port may not be able to supply enough power to your Proteus. This is easily remedied with a power supply connected to Proteus's USB Adapter; here's how it works.

- a) Attach one end of your Cable to your Proteus and the other end to the USB Adapter.
- b) Connect the USB Adapter to a USB port on your PC.
- c) Connect a power source providing between 9 and 15 VDC (such as a wall wart).
- d) Launch your Proteus Control Software as usual.



Note: Do not connect your USB Adapter to any power source greater than 15 VDC unless that power source is protected by a ground-fault interrupter (GFI). GFI's are inexpensive and a necessary safety precaution.

Problems? No problem. E-mail us at support@proteus-instruments.com or call +44 1527 433221.